



## ADJUSTING THE UPPER AUGER

Raise the upper auger to the unload position. Engage the upper auger into the lower auger by rotating driveline. Check the spacing between the 4-Hole Flange Bearing and the Head Pan of the Upper Auger Tube. Adjust the 1-1/4" Hex Nuts along the Threaded Shaft of the Upper Flighting until the 4-Hole Flange Bearing is 1/8" to 3/16" above the Head Pan of the Upper Auger Tube. Tighten the 1-1/4" Hex Nuts to lock the 4-Hole Flange Bearing into place.